



# Freestanding Electric Range with Double Ovens

## PRODUCT MODEL NUMBERS

GGE350LW

**Electrical:** To properly install your range, you must determine the type of electrical connection you will be using and follow the instructions provided for it here.

- Range must be connected to the proper electrical voltage and frequency as specified on the model/serial number rating label. The model/serial number rating label is located on the bottom right front of the toe kick plate. Refer to the figures in the "Product Dimensions" section of the "Location Requirements" section.
- This range is manufactured with the neutral terminal connected to the cabinet. Use a 3-wire, UL listed, 40- or 50-amp power supply cord (pigtail) (see following Range Rating chart). If local codes do not permit ground through the neutral, use a 4-wire power supply cord rated at 250 volts, 40 or 50 amps and investigated for use with ranges.

## Range Rating\*

### Specified Rating of Power Supply Cord Kit and Circuit Protection

120/240 Volts	120/208 Volts	Amps
8.8 - 16.5 KW	7.8 - 12.5 KW	40 or 50**
16.6 - 22.5 KW	12.6 - 18.5 KW	50

\*The NEC calculated load is less than the total connected load listed on the model/serial rating label.

\*\*If connecting to a 50-amp circuit, use a 50-amp rated cord with kit. For 50-amp rated cord kits, use kits that specify use with a nominal 1 $\frac{3}{8}$ " (34.9 mm) diameter connection opening.

• A circuit breaker is recommended.

## CABINET OPENING DIMENSIONS

Cabinet opening dimensions shown are for 25" (64.0 cm) countertop depth, 24" (61.0 cm) base cabinet depth and 36" (91.4 cm) countertop height.


**IMPORTANT:** If installing a range hood or microwave hood combination above the range, follow the range hood or microwave hood combination installation instructions for dimensional clearances above the cooktop surface.

A freestanding range may be installed next to combustible walls with zero clearance.

**\*NOTE:** 24" (61.0 cm) minimum when bottom of wood or metal cabinet is covered by not less than 1/4" (0.64 cm) flame retardant millboard covered with not less than No. 28 MSG sheet steel, 0.015" (0.4 mm) stainless steel, 0.024" (0.6 mm) aluminum or 0.020" (0.5 mm) copper.


30" (76.2 cm) minimum clearance between the top of the cooking platform and the bottom of an uncovered wood or metal cabinet.

## PRODUCT DIMENSIONS



A. 46 $\frac{7}{8}$ " (119.9 cm)  
 B. Model/serial number rating label (located on bottom right front of the toe kick plate)  
 C. 35 $\frac{7}{8}$ " (91.4 cm)  
 D. 29 $\frac{7}{8}$ " (75.9 cm)  
 E. 26 $\frac{5}{16}$ " - 27 $\frac{1}{4}$ " (66.8 - 69.2 cm)\*

\*Excludes handle. Dimension given is from wall to front of oven door and will vary based on electric outlet receptacle installation.



A. 13" (33 cm) upper cabinet depth  
 B. 30" (76.2 cm) min. opening width  
 C. For minimum clearance to the top of the cooktop, see NOTE.  
 D. 30" (76.2 cm) min. opening width  
 E. Cabinet door or hinge should not extend into cutout.  
 F. 3-wire shaded area - 7" (17.8 cm) min. from left side cabinet, 5 $\frac{3}{4}$ " (14.6 cm) max. from floor, 6" (15.2 cm) max. width\*  
 G. 4-wire shaded area - 10" (25.4 cm) min. from right side cabinet, 5 $\frac{3}{4}$ " (14.6 cm) max. from floor, 6" (15.2 cm) max. width\*  
 H. 1 $\frac{1}{2}$ " (3.8 cm) min. from floor if using a flush mount outlet.

\*Nothing located in shaded areas can extend more than 1 $\frac{1}{2}$ " (3.8 cm) from wall or range will not slide all the way back.